

ALPHABETICAL INDEX

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

SECTION **IDX**

IDX

ALPHABETICAL INDEX

A

A/C relay.....	HA-32
A/C service data specification.....	HA-22, 33
A/C trouble diagnoses (auto A/C)	HA-24
A/C trouble diagnoses (manual A/C)	HA-6
A/C, A - Wiring diagram	HA-25
A/C, M - Wiring diagram.....	HA-7, 10, 13, 16
Accelerator control system (VG33E engine)	FE-3
Air cleaner filter replacement.....	MA-11
Air flow meter - See Mass air flow sensor	EC-51
Angular tightening application (VG33E engine)	EM-2
A/T - Wiring diagram - AT - MAIN.....	AT-9
A/T - Wiring diagram - AT - VSS A/T.....	AT-10
A/T Wiring diagram - AT - ENG SS	AT-24
A/T Wiring diagram AT - BA/FTS.....	AT-22
A/T Wiring diagram AT - LPSV	AT-27
A/T Wiring diagram AT - NONDTC	AT-28
A/T Wiring diagram AT - OVRCSV	AT-20
A/T Wiring diagram AT - SSV/A.....	AT-18
A/T Wiring diagram AT - SSV/B.....	AT-19
A/T Wiring diagram AT - TCV	AT-21
A/T Wiring diagram AT - TPS.....	AT-13
A/T Wiring diagram AT - VSSMTR.....	AT-11
Audio	EL-65
AUDIO - Wiring diagram.....	EL-65

B

Back-up lamp	EL-20
BACK/L - Wiring diagram.....	EL-20
Basic inspection	EC-32
Boring/horning cylinder block (VG33E engine)	EM-52
BPT valve	EC-82

C

Camshaft inspection (VG33E engine)	EM-34
CHARGE - Wiring diagram.....	EL-13
Charging system	EL-13
Chassis and body maintenance	MA-16
CHIME - Wiring diagram.....	EL-64
Combination meter.....	EL-35
Combination switch.....	EL-14
Compression pressure (VG33E engine).....	EM-13
Connecting rod (VG33E engine)	EM-50
Connecting rod bearing clearance (VG33E engine)	EM-55
Connecting rod bushing clearance (VG33E engine)	EM-56
Converter housing installation.....	AT-33

COOL/F - Wiring diagram (KA24DE engine)	LC-18
COOL/F - Wiring diagram (QD & TD engines)	LC-19
Coolant replacement.....	MA-7
Cooling circuit (VG33E engine)	LC-8
Cooling fan (KA24DE, QD & TD engines)	LC-20
Cooling fan (VG33E engine)	LC-15
Cooling fan control	EC-92
Cooling fan control system (KA24DE engine)	LC-18
Cooling fan control system (QD & TD engines)	LC-19
Crankshaft (VG33E engine)	EM-53, 57
Cylinder block (QD32 engine)	EM-61
Cylinder block (VG33E engine)	EM-48
Cylinder block boring (VG33E engine)	EM-52
Cylinder head (VG33E engine).....	EM-28
Cylinder head bolt tightening (VG33E engine)	EM-42

D

Door trim	BT-6
Drive belt inspection	MA-6
Drive plate runout (VG33E engine)	EM-56

E

ECM input/output signal	EC-43
ECM relay.....	EC-49
ECTS - Wiring diagram	EC-52
EGR control valve	EC-82
EGR valve & EVAP canister purge control solenoid valve.....	EC-82
Engine control circuit diagram.....	EC-16
Engine control component parts location	EC-18
Engine control system diagram and chart.....	EC-17
Engine coolant temperature sensor (ECTS).....	EC-52
Engine oil filter replacement	MA-12
Engine oil replacement	MA-11
Engine outer component parts (VG33E engine)	EM-9
Engine removal (QD32 engine)	EM-60
Engine removal (VG33E engine).....	EM-46
Engine serial number	GI-8
EVAP canister purge control valve.....	EC-23
EVAP vapor lines inspection.....	MA-15
Evaporative emission (EVAP) system.....	EC-23
Exhaust system (VG33E engine)	FE-5
Exhaust system inspection	MA-16
Exterior.....	BT-3

ALPHABETICAL INDEX

F

F/FOG - Wiring diagram	EL-22
FICD - Wiring diagram	EC-7, 75
Fluids	MA-5
Flywheel runout (VG33E engine)	EM-56
Fog lamp, front	EL-22
Fog lamp, rear	EL-25
Front fog lamp	EL-22
Fuel filter replacement	MA-10
Fuel injector	EC-89
Fuel line inspection	MA-10
Fuse block	Foldout

G

Gauges	EL-35
--------------	-------

H

H/AIM - Wiring diagram	EL-16
Harness layout	EL-72
Headlamp aiming control	EL-16
Heated oxygen sensor (HO2S) monitor	EC-26
Heated oxygen sensor heater	EC-74
HO2S - Wiring diagram	EC-69
Hydraulic lash adjuster inspection (VG33E engine)	EM-39

I

Ignition coil	EC-86
ILL - Wiring diagram	EL-31
Illumination	EL-31
INJECT - Wiring diagram	EC-89
Injector	EC-89
Interior lamp	EL-30

K

Knock sensor (KS)	EC-65
-------------------------	-------

L

License lamp	EL-18
Liquid gasket application (VG33E engine)	EM-2
LOAD - Wiring diagram	EC-5
LSV (Load sensing valve)	BR-2
Lubricants	MA-5
Lubrication circuit (VG33E engine)	LC-4

M

MAFS - Wiring diagram	EC-51
MAIN - Wiring diagram	EC-49
Maintenance (engine)	MA-6
Malfunction indicator lamp (MIL)	EC-24
Mass air flow sensor (MAFS)	EC-51
Meter	EL-35
METER - Wiring diagram	EL-39
Model variation	GI-4
M/T removal and installation	MT-2
Multiport fuel injection (MFI) system	EC-22

N

NATS (Nissan anti-theft system)	EL-70
NATS - Wiring diagram	EL-70
Neutral position switch	EC-88
NVH troubleshooting (EM) (VG33E engine)	EM-7

O

Oil change (capacity)	MA-5
Oil change (interval)	MA-3
Oil pan (VG33E engine)	EM-14
Oil pressure (VG33E engine)	LC-5
Oil pressure relief valve (VG33E engine)	LC-7
Oil pump (VG33E engine)	LC-6
Oil pump regulator valve (VG33E engine)	LC-7
Oil seal replacement (VG33E engine)	EM-25
On board diagnostic system	EC-24
Oversize piston (VG33E engine)	EM-52

P

Parking lamp	EL-18
Periodic maintenance (except for Europe)	MA-3
Pilot bushing replacement (VG33E engine)	EM-59
Piston assembly (VG33E engine)	EM-57
Piston pin inspection (VG33E engine)	EM-49
Piston ring inspection (VG33E engine)	EM-50
Piston to bore clearance (VG33E engine)	EM-51
PNP/SW - Wiring diagram	EC-88
POWER - Wiring diagram	EL-5
Power supply routing	EL-4
Power transistor	EC-86
Power transistor & ignition coil	EC-83

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

ALPHABETICAL INDEX

R

Radiator (QD32 engine)	LC-17
Radiator (VG33E engine)	LC-13
Rear bumper	BT-2
Rear fog lamp	EL-25
Refrigerant connection precaution	HA-3
Refrigerant lines	HA-19
Refrigeration cycle.....	HA-5
Removal and installation (A/T).....	AT-32
R/FOG - Wiring diagram.....	EL-25, 27
ROOM/L - Wiring diagram	EL-30

S

Self-diagnostic results	EC-24
Shift schedule.....	AT-36
SMJ (super multiple junction).....	Foldout
Spark plug replacement.....	MA-13
SRS - Wiring diagram	RS-2
Starting system	EL-12
Steering wheel and column	ST-2
Supplemental restraint system - Wiring diagram.....	RS-2
Symptom matrix chart	EC-36

T

Tail lamp.....	EL-18
----------------	-------

TAIL/L - Wiring diagram	EL-18
TCM circuit diagram.....	AT-3
Thermostat (QD32 engine).....	LC-16
Thermostat (VG33E engine).....	LC-12
Throttle position sensor adjustment	EC-32
Throttle position switch	AT-17, 26
Timing belt (VG33E engine)	EM-18
Torque converter installation	AT-33

V

Valve clearance (VG33E engine)	EM-64
Valve guide (VG33E engine)	EM-36
Valve seat (VG33E engine)	EM-37
Valve spring (VG33E engine)	EM-39
Vehicle identification number.....	GI-7
Vehicle speed sensor (VSS)	EC-53
VSS - Wiring diagram	EC-53

W

WARN - Wiring diagram	EL-46
Warning chime	EL-64
Warning lamps	EL-44
Water pump (VG33E engine)	LC-10
Wiring Diagram (Cell code) list.....	EL-96
Wrist pin - See Piston pin inspection (VG33E engine)	EM-49