

# ALPHABETICAL INDEX

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

## SECTION **IDX**

**IDX**

## ALPHABETICAL INDEX

### A

AAC/V - Wiring diagram.....	EC-102
A/C HFC134a (R134a) system service tools .....	HA-4
A/C trouble diagnoses (manual A/C) .....	HA-5
A/C, M - Wiring diagram .....	HA-6
Accelerator control system .....	FE-2
Accelerator wire adjustment .....	FE-3
Air conditioner cut control .....	EC-20
Air flow meter - See Mass air flow sensor .....	EC-74
AIRREG - Wiring diagram.....	EC-131
Alternator.....	EL-20
Angular tightening application.....	EM-2
Antenna.....	EL-54
A/T - Wiring diagram - AT - MAIN.....	AT-14
A/T - Wiring diagram - AT - VSS A/T.....	AT-16
A/T IND - Wiring diagram .....	EL-48
AT indicator lamp .....	EL-48
A/T self-diagnoses.....	AT-7
A/T shift lock system .....	AT-43
A/T shift lock system - Wiring diagram .....	AT-44
A/T Wiring diagram - AT - ENG SS .....	AT-33
A/T Wiring diagram AT - BA/FTS.....	AT-31
A/T Wiring diagram AT - LPSV .....	AT-35
A/T Wiring diagram AT - NONDTC .....	AT-37
A/T Wiring diagram AT - OVRCSV .....	AT-27
A/T Wiring diagram AT - SSV/A.....	AT-23
A/T Wiring diagram AT - SSV/B.....	AT-25
A/T Wiring diagram AT - TCV .....	AT-29
A/T Wiring diagram AT - TPS.....	AT-20
A/T Wiring diagram AT - VSSMTR .....	AT-18
Audio .....	EL-50
AUDIO - Wiring diagram.....	EL-50
Auxiliary air control (AAC) valve .....	EC-102

### B

Back window .....	BT-6
Back-up lamp .....	EL-23
BACK/L - Wiring diagram.....	EL-23
Basic inspection .....	EC-43
Battery.....	EL-12
Bulb specifications .....	EL-84
Bumper, front .....	BT-2
Bumper, rear .....	BT-5

### C

Camshaft inspection .....	EM-26
Camshaft position sensor (CMPS).....	EC-67
Canister-See EVAP canister .....	EC-21
CHARGE - Wiring diagram.....	EL-17
Charging system .....	EL-17
Clutch fluid level.....	MA-19

Clutch operating cylinder .....	CL-5
Clutch pedal.....	CL-3
Clutch withdrawal lever.....	CL-6
CMPS - Wiring diagram .....	EC-67
Combination lamp, front, removal and installation .....	BT-2
Combination lamp, rear, removal and installation .....	BT-6
Combination meter.....	EL-29
Compression pressure.....	EM-8
Compressor mounting .....	HA-18
Connecting rod bearing clearance.....	EM-46
Connecting rod bushing clearance .....	EM-47
CONSULT for engine .....	EC-32
Control units (terminal arrangement) .....	Foldout
Converter housing installation.....	AT-46
Coolant mixture ratio.....	MA-10
Crank angle sensor built into distributor - See Camshaft position sensor .....	EC-67
“Crankcase emission control system - See positive crankcase ventilation” .....	EC-23
Crankcase ventilation system - See Positive crankcase ventilation .....	EC-23
Crankshaft.....	EM-44, 49
Crankshaft position sensor (POS) .....	EC-67
Crankshaft position sensor (REF).....	EC-67
Cylinder block .....	EM-40
Cylinder head.....	EM-21

### D

Data link connector for Consult.....	EC-32
DEF - Wiring diagram .....	EL-56
Diagnostic trouble code (DTC) for OBD system .....	EC-27
Differential carrier assembly.....	PD-19
Distributor ignition (DI) system.....	EC-19
Door mirror.....	BT-8
Drive pinion height .....	PD-16

### E

ECCS relay .....	EC-5, 61
ECM input/output signal.....	EC-55
ECTS - Wiring diagram .....	EC-79
EGR - Wiring diagram.....	EC-138
Electrical ignition system.....	EC-19
Engine control circuit diagram.....	EC-11
Engine control component parts location .....	EC-13
Engine control system diagram and chart.....	EC-12
Engine coolant temperature sensor (ECTS).....	EC-79
Engine fail-safe system .....	EC-49
Engine removal .....	EM-38
Engine serial number.....	GI-11
EVAP canister.....	EC-21

# ALPHABETICAL INDEX

EVAP canister purge control valve.....EC-21  
 Evaporative emission (EVAP) system.....EC-21  
 Exhaust system .....FE-8  
 Exterior.....BT-6

## F

FICD - Wiring diagram .....EC-9  
 Fluids.....MA-8  
 Flywheel runout.....EM-48  
 F/PUMP - Wiring diagram .....EC-122  
 Front bumper .....BT-2  
 Front combination lamp removal and  
 installation .....BT-2  
 Fuel check valve .....EC-22  
 Fuel cut control (at no load & high  
 engine speed).....EC-20  
 Fuel injector.....EC-114  
 Fuel pressure check.....EC-24  
 Fuel pressure regulator.....EC-24  
 Fuel pressure release .....EC-24  
 Fuel pump .....EC-122  
 Fuel pump relay .....EC-122, 126  
 Fuel system .....FE-4  
 Fuel tank vacuum relief valve .....EC-22

## G

Gauges.....EL-29  
 Gear components (M/T) (FS5W71C).....MT-3  
 Gear components (M/T) (QD32).....MT-8  
 Gear components (M/T) (VG30E).....MT-6  
 Grease .....MA-8

## H

Harness layout.....EL-60  
 Headlamp.....EL-21  
 HFC134a (R134a) system service tools.....HA-4  
 Hood.....BT-2  
 Horn .....EL-49  
 HORN - Wiring diagram.....EL-49  
 How to erase DTC for OBD system .....EC-27

## I

IACV-AAC valve .....EC-102, 106  
 Identification .....HA-2  
 Identification plate.....GI-10  
 IGN/SG - Wiring diagram.....EC-7, 84  
 Ignition coil .....EC-89  
 ILL - Wiring diagram .....EL-25  
 Illumination.....EL-25  
 INJECT - Wiring diagram .....EC-114

Injector .....EC-114, 119

## L

Liquid gasket application .....EM-2  
 Location of electrical units .....EL-57  
 Lubricants.....MA-8

## M

MAFS - Wiring diagram.....EC-74  
 MAIN - Wiring diagram .....EC-5, 61  
 Malfunction indicator lamp (MIL).....EC-29  
 Manual transmission number .....GI-12  
 Mass air flow sensor (MAFS).....EC-74  
 Meter.....EL-29  
 METER - Wiring diagram.....EL-30  
 MIL & Data link connectors circuit .....EC-135  
 MIRROR - Wiring diagram.....EL-55  
 Mirror, door.....BT-8  
 Mirror, out side.....BT-8  
 Model variation .....GI-5  
 Molding - See Exterior .....BT-6  
 M/T removal and installation  
 (FS5R30A).....MT-4  
 Multiport fuel injection (MFI) system.....EC-17

## N

Neutral position switch .....EC-107

## O

Oil change (capacity) .....MA-8  
 Oil change (interval).....MA-5  
 Oil pan (engine) .....EM-9  
 Oil seal replacement (engine).....EM-19  
 On board diagnostic system .....EC-27  
 Operating cylinder (clutch).....CL-5  
 Out side mirror .....BT-8

## P

P/ANT - Wiring diagram.....EL-54  
 Periodic maintenance (except for  
 Europe).....MA-5  
 Piston pin inspection.....EM-41  
 Piston ring inspection.....EM-42  
 Piston to bore clearance.....EM-43  
 PLA - Wiring diagram .....EC-140  
 PNP/SW - Wiring diagram .....EC-107  
 POWER - Wiring diagram.....EL-5  
 Power door mirror .....EL-55  
 Power steering oil pump.....ST-3

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

## ALPHABETICAL INDEX

Power supply routing .....EL-4  
Power transistor .....EC-89  
Power transistor & ignition coil.....EC-89  
Precautions for Leak detection dye .....HA-2  
PST/SW - Wiring diagram.....EC-127

### Q

Quick-glow system .....EC-137

### R

Rear combination lamp removal and  
installation .....BT-6  
Rear window defogger.....EL-56  
Refrigerant connection precaution .....HA-3  
Refrigerant lines .....HA-16  
Removal and installation (A/T).....AT-45  
Resistor .....EC-89  
Road wheel size .....GI-13

### S

Seal - See Exterior .....BT-6  
Self-diagnostic results .....EC-29  
SHIFT - Wiring diagram .....AT-44  
Shift control components (M/T)  
(FS5R30A).....MT-9  
Shift lock system .....AT-43  
Shift schedule.....AT-48  
SMJ (super multiple junction).....Foldout  
Solenoid timer .....EC-140  
SRS - Wiring diagram .....RS-3  
S/SIG - Wiring diagram .....EC-120  
START - Wiring diagram.....EL-13  
Start signal .....EC-120  
Starter .....EL-16  
Starting system .....EL-13  
Stop lamp.....EL-22

STOP/L - Wiring diagram.....EL-22  
Supplemental restraint system - Wiring  
diagram.....RS-3  
Symptom matrix chart .....EC-50

### T

TCM circuit diagram.....AT-4  
Throttle position sensor (TPS) .....EC-93  
Throttle position sensor adjustment.....EC-43  
Timing belt.....EM-12  
Tire size .....GI-13  
Torque converter installation .....AT-46  
TPS - Wiring diagram.....EC-93  
Transfer serial number.....GI-11  
Transmission case (M/T) (FS5R30A).....MT-5  
Transmission case (M/T) (FS5W71C).....MT-2  
Transmission serial number .....GI-12

### V

Valve guide .....EM-28  
Valve seat .....EM-29  
Valve spring .....EM-31  
Vehicle speed sensor (VSS) .....EC-98  
Viscosity number (SAE).....MA-9  
VSS - Wiring diagram .....EC-98

### W

WARN - Wiring diagram .....EL-35  
Warning lamps .....EL-34  
Weatherstrip - See Exterior .....BT-6  
Wheel size .....GI-13  
Window, back.....BT-6  
Wiring Diagram (Cell code) list.....EL-85  
Withdrawal lever (clutch) .....CL-6