

ALPHABETICAL INDEX

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

SECTION **IDX**

IDX

ALPHABETICAL INDEX

A

ABS - Wiring diagramBR-3
A/C trouble diagnoses (manual A/C)HA-2
A/C, M - Wiring diagramHA-3
Anti-lock brake system - Wiring
diagramBR-2

C

Camshaft (ZD30DDT engine)EM-5
Camshaft inspection (ZD30DDT
engine)EM-5
Center case (Transfer)TF-3
Counter gear (Transfer)TF-4
Crankshaft (ZD30DDT engine)EM-12
Cylinder block (YD25DDTi engine)EM-3
Cylinder block (ZD30DDT engine)EM-12
Cylinder head (YD25DDTi engine)EM-2
Cylinder head (ZD30DDT engine)EM-10

D

Drive chain (Transfer)TF-4

F

FICD - Wiring diagramEC-2
FluidsMA-2
Front case (Transfer)TF-3
Front drive shaft (Transfer)TF-4

G

GLOW - Wiring diagramEC-3, 4
GreaseMA-2

H

Harness layoutEL-12

I

ILL - Wiring diagramEL-3
IlluminationEL-3
Interior lampEL-2

L

LubricantsMA-2

M

Main gear (Transfer)TF-4
Mainshaft (Transfer)TF-4
Model variationGI-4

O

Oil change (capacity)MA-2
Oversize piston (YD25DDTi engine)EM-15

P

Piston to bore clearance (YD25DDTi
engine)EM-3
Power windowEL-5

R

RadiatorLC-2
Rear case (Transfer)TF-3
Removal and installation (Transfer)TF-2
ROOM/L - Wiring diagramEL-2

S

Shift control (Transfer)TF-5
SMJ (super multiple junction)Foldout
SRS - Wiring diagramRS-2
Supplemental restraint system - Wiring
diagramRS-2

T

THEFT - Wiring diagramEL-10
Theft warning systemEL-10
Timing gear (ZD30DDT engine)EM-8

V

Valve clearance (ZD30DDT engine)EM-7
Valve guide (ZD30DDT engine)EM-11
Valve lifter (ZD30DDT engine)EM-6
Vehicle identification numberGI-6

ALPHABETICAL INDEX

W

Wiring Diagram (Cell code) list.....EL-27

- GI
- MA
- EM
- LC
- EC
- FE
- CL
- MT
- AT
- TF
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL