

ALPHABETICAL INDEX

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

SECTION **IDX**

IDX

ALPHABETICAL INDEX

A

ABS - Wiring diagramBR-3, 9
A/C service data specification.....HA-2
Accelerator position sensor.....EC-46
Antenna.....EL-62
Anti-lock brake system - Wiring
 diagram.....BR-3
A/T Wiring diagram - AT - ENG SSAT-4
A/T Wiring diagram AT - NONDTCAT-5
A/T Wiring diagram AT - VSSMTRAT-2
Audio.....EL-60
AUDIO - Wiring diagram.....EL-60

B

Back-up lampEL-22
Bumper, frontBT-2

C

CHARGE - Wiring diagram.....EL-12, 13
Charging systemEL-11
Chassis and body maintenanceMA-3
ClockEL-59
CLOCK - Wiring diagram.....EL-59
Combination meter.....EL-31
Cooling fan.....LC-2
Cooling fan controlEC-30
Cylinder head.....EM-3

D

D/LOCK - Wiring diagram.....EL-76

E

ECCS-D control module.....EC-53
ECMRLY - Wiring diagram.....EC-53
Electronic fuel injection pump.....EC-45, 48, 49, 50,
 51, 52, 56
Engine control circuit diagram.....EC-67
Engine outer component partsEM-2

F

F/LID - Wiring diagramEL-80
Fluids.....MA-2
Fog lamp, front.....EL-24
Front bumperBT-2
Front fog lamp.....EL-24
FUEL FILLER LID OPENER.....EL-80

Fuse blockFoldout

G

Gauges.....EL-31
Gear components (M/T)MT-2
GLOW - Wiring diagram.....EC-9
GreaseMA-2

H

H/AIM - Wiring diagramEL-18
Harness layoutEL-88
Hazard warning lamp.....EL-25
Headlamp.....EL-14
Heat up switchEC-62, 71
HEATUP - Wiring diagramEC-62, 71
H/LAMP - Wiring diagram.....EL-14

I

ILL - Wiring diagramEL-27
IlluminationEL-27
Interior lampEL-30

K

Keyless entry system - See Multi-re-
 mote control system.....EL-81

L

License lamp.....EL-19
Lubricants.....MA-2

M

MAIN - Wiring diagram.....EC-21
MeterEL-31
METER - Wiring diagram.....EL-31
MIL & Data link connectors circuitEC-5
MIL/DL - Wiring diagramEC-5, 6, 7, 8, 63, 72
MIRROR - Wiring diagram.....EL-63
Model variationGI-2
M/T major overhaulMT-2
MULTI - Wiring diagram.....EL-82
Multi-remote control system.....EL-81

ALPHABETICAL INDEX

O

Oil change (capacity).....MA-2

P

Park/Neutral position switch.....EC-58
 Parking lampEL-19
 POWER - Wiring diagram.....EL-4
 Power door mirrorEL-63
 Power supply routingEL-3
 Power windowEL-66

Q

Quick-glow systemEC-9

R

Room lamp.....EL-30
 ROOM/L - Wiring diagramEL-30

S

SMJ (super multiple junction).....Foldout

SRS - Wiring diagramRS-2
 Stop lamp.....EL-21
 STOP/L - Wiring diagram.....EL-21
 Supplemental restraint system - Wiring
 diagramRS-2

T

Tail lamp.....EL-19
 TAIL/L - Wiring diagramEL-19
 TURN - Wiring diagramEL-25
 Turn signal lampEL-25

V

Vehicle identification number.....GI-4
 Vehicle speed sensor (VSS).....EC-3, 28, 68
 VSS - Wiring diagramEC-3, 4

W

WARN - Wiring diagramEL-40
 Warning lampsEL-39
 Water pumpLC-2
 WINDOW - Wiring diagramEL-67

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX