

SECTION **HA**

MODIFICATION NOTICE:

- Wiring diagrams have been changed for LHD models with KA, YD and ZD engines. (manual A/C)


CONTENTS

MANUAL	
TROUBLE DIAGNOSES	2
Circuit Diagram - A/C, M -	2

Wiring Diagram - A/C, M -/LHD Models with KA, YD and ZD Engines.....	3
---	---





GI
MA
EM
LC
EC
FE
CL
MT
AT
TF
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Circuit Diagram — A/C, M —



Wiring Diagram — A/C, M —/LHD Models with KA, YD and ZD Engines

HA-A/C,M-01



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS


BT

HA



EL

IDX

HA-A/C,M-02



M5, E101

Wiring Diagram — A/C, M —/LHD Models with
KA, YD and ZD Engines (Cont'd)

Refer to last page (Foldout page).

M5, E101

M32